



OPERATOR'S INSTRUCTION MANUAL

MODEL : **502 000** _____

ENGINE MODEL : _____

SERIAL : _____

ENGINE SERIAL : _____

DATE OF PURCHASE : _____

PURCHASED FROM : _____



⚠️ WARNING ⚠️

THIS PRODUCT IS DESIGNED AND MANUFACTURED TO PROVIDE SAFE AND DEPENDABLE SERVICE IF OPERATED ACCORDING TO INSTRUCTIONS. THE MANUFACTURER PROVIDES THE FOLLOWING INSTRUCTIONS FOR USE AND CARE OF THIS EQUIPMENT AND RELIES UPON THE PURCHASER TO SEE TO IT THAT THESE INSTRUCTIONS ARE MADE CLEAR TO THE PERSONS WHO WILL ACTUALLY BE USING THE EQUIPMENT. FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.



Index

INTRODUCTION	3
PREPARATION	4
Operateur	4
WEAR PROPER ATTIRE	4
ROOF PREPARATION	4
Inspect roof deck	4
Warning line system	4
SPECIAL WARRANTY NOTES	4
SAFETY INSTRUCTIONS	5
NAME PLATE AND SERIAL NUMBER TAGS	5
SAFETY FEATURES MECHANICAL POWER UNIT / SAFETY FIRST	6
IMPORTANT	6
WEIGHT LOAD CAPACITY OF DIFFERENT MODELS	6
POWER UNIT WEIGHT	6
WIRE ROPE	6
BUILD-UP	7
SAFETY HOOK	7
CAPACITY	7
PRE-START CHECKLIST	7
PRE-HOISTING CHECKLIST	7
RULES FOR HOISTING	8
RAISING TO ROOF	9
ASSEMBLY	10
INSTALLING POWER UNIT	12
OPERATING THE MECHANICAL POWER UNIT (502500)	12
HOISTING THE LOAD	12
LOWERING THE LOAD	13
SAFETY HAZARDS	14
FALLS	14
BURNS	14
HEAVY LIFTING	14
FIRE/EXPLOSION	15
ELECTROCUTION	15
FALLING OBJECTS	15
FLYING OBJECTS	15
UNGUARDED MACHINERY	15



INTRODUCTION

502 000 - TT1000 HOIST

Thank you for purchasing this quality GRIZZLY product. With proper use and care this hoist will provide many years of reliable service. For the safety of all job-site personnel it is mandatory that the instructions provided for the use and handling of the equipment be read and thoroughly understood by the operators.



CAUTION

INTENDED USE: THIS MACHINE IS INTENDED TO BE USED ON FLAT, LEVEL ROOFS ONLY FOR THE SOLE PURPOSE OF LIFTING AND LOWERING EQUIPMENT, MATERIAL AND SUPPLIES TO AND FROM THE ROOF. ANY OTHER USE OF THIS EQUIPMENT VOIDS THE MANUFACTURER'S WARRANTY AND IS THE SOLE RESPONSIBILITY OF THE OWNER/USER, SHOULD ANY DAMAGE OR INJURY OCCUR.



PREPARATION

OPERATOR

START BY READING AND FULLY UNDERSTANDING OPERATING INSTRUCTIONS. IF SOMETHING IS NOT UNDERSTOOD, HAVE SOMEONE ELSE READ AND EXPLAIN THE INSTRUCTIONS TO THE OPERATOR OR CALL THE MANUFACTURER FOR INFORMATION. AN UNINFORMED OPERATOR CAN SUBJECT HIMSELF AND OTHERS TO DEATH OR SERIOUS INJURY.

WEAR PROPER ATTIRE

Safety glasses are recommended and must be worn if any roof cutting or scraping is being done in the vicinity. Safety glasses and or face shield are also necessary when working with hot stuff.

Wear properly fitting clothes. Tight clothing can restrict movement and slow down reaction time in a dangerous situation. Loose fitting clothing can be dangerous and cause serious injury if it gets caught in moving mechanical parts. Wear a long-sleeved shirt, buttoned at the cuffs, safety shoes, and pants without cuffs, and knit wrist type gloves.

A hard hat must be worn by operator when working on a job site.

ROOF PREPARATION

INSPECT ROOF DECK

Before allowing equipment and personnel access to roof, make certain roof is strong enough to support the weight. Check load limits of deck with owner, builder or architect. Clear the work area of all potentially dangerous obstacles that could cause personal injury to the operator or others. Keep unauthorized people away from construction area. Check to see that all roof openings are guarded to protect against falls.

WARNING LINE SYSTEM

When operating parallel to roof edge warning line system must be at least six feet from edge. When operating perpendicular to edge warning line must be ten feet from roof edge.

PLEASE READ BEFORE HANDLING HOIST

WARNING: THESE HOISTS ARE NOT FOR TRANSPORTING OR HANDLING OF PERSONS. NO PERSONS SHALL BE ALLOWED TO RIDE ON MATERIAL HOISTS.

SPECIAL WARRANTY NOTES

Manufacturer is NOT responsible for warranty if equipment is subject to unusual, improper use or abuse by person(s) using the equipment, or for purposes for which it was not intended for. Warranty is further void if any modifications are made to the equipment by the owner. Collisions, overturn, dropping, water damage, or damage to equipment after being shipped by manufacturer, also voids the warranty.



SAFETY INSTRUCTIONS

1. After the hoist is assembled, make sure that all pins on the frame and power unit are properly placed.
2. Verify that all nuts and bolts on the frame are properly fastened. If any are loose, make sure that they are tightened before operating the hoist to ensure the operator's safety and the safety of others.
3. The cable located on the back of the track must be fastened to a secure object on the roof in a manner that it will not come loose under pressure.
4. The fences located on the front frame must be swung outward to protect the operator from accidentally falling off the roof edge while operating the hoist.
5. Make sure to always have enough counterweights on the rear weight base. It is important to use 1-1/2 times the weight capacity of the hoist; 1500lbs. After placing the counterweights secure them to the hoist frame using a wire cable or chain to prevent them from being removed or falling off of base in the event of sudden impact load.

WARNING: NEVER ATTEMPT TO LIFT MORE THAN THE MAXIMUM RATED LIFT LIMIT, DAMAGE TO THE HOIST AND/OR INJURY TO THE OPERATOR COULD RESULT.

6. Always keep in mind the maximum rated load of the hoist that you are using.
7. Check the hoist cable for broken strands, if any are found then the hoist cable should be immediately replaced.
8. Check the hoist braking system for wear and proper operation by lifting a load one or two feet off the ground and applying brake to check it's performance, adjust if necessary. Do not use hoist if unable to adjust properly.
9. Always test the running of the hoist with a small amount of weight before lifting very heavy objects.

WARNING: DO NOT APPLY GREASE OR OILY SUBSTANCES ON THE BRAKE ROPE OR ON THE BRAKE DRUM.

10. Grease all moving parts on the hoist power unit (drum bearings, idler) verify the belt condition.
11. The engine oil and fuel level should be checked and topped off before starting. For all other engine maintenance, please refer to the engine manual.
12. You are now ready to start the engine.

NAME PLATE AND SERIAL NUMBER TAGS

The name plate and serial number tag is located on the power unit frame. Use the model number and serial number when referring to your mechanical or hydraulic hoist power unit for parts or service.

Capacities of track hoist and power unit combinations:

<u>HOIST MODEL</u>	<u>POWER UNIT MODEL</u>	<u>CAPACITY</u>
502000 - TT1000	502500 9 HP	1000 LBS



SAFETY FEATURES MECHANICAL POWER UNIT / SAFETY FIRST

- Dual controls, one handle for clutch and one handle for brake.
- Load is powered up by tensioning belt with clutch lever.
- Brake automatically activates if brake handle is released.
- For raising loads the pawl should be used.

IMPORTANT

To reduce the possibility of personal injury or property damage;

Read, fully understand and follow these instructions prior to assembly and operation. Retain these instructions. They should be kept within the instruction tube on hoist frame for reference. Counterweight must be one and one half times the weight of the load. This will insure a 3:1 safety factor.

Inspect the cable for damage or wear prior to each use.
The cable end-loop must always be bolted to the drum.
Always leave at least four wraps of the cable on the drum.
Do not exceed the rated capacity of the unit.

WEIGHT LOAD CAPACITY OF DIFFÉRENT MODELS

<u>Power Unit Model</u>	<u>Capacity</u>	<u>HP</u>	<u>Cable supplied</u>
502 500	600 LBS single line	9 HP	200 feet
502 500	1000 LBS double line	9 HP	200 feet

POWER UNIT WEIGHT 502500 215 LBS

WIRE ROPE

Inspect the wire rope frequently for signs of wear: Always inspect prior to operation. The standard wire rope supplied with the unit has 133 strands. If 13 or more of these strands are broken, pinched, or unravelled, the wire rope must be replaced. Regular inspection and replacement will protect your investment.



BUILD-UP

The speed and lifting capability of the unit is determined by the diameter of the drum. As the wire rope is wound onto the drum, the diameter increases, which increases the lifting speed, but decreases lifting capacity. Likewise, when there is less wire rope build-up, the capacity is greater, but the speed is lowered.

SAFETY HOOK

All hooks come equipped with a safety latch. If the latch should become broken, bent or disassembled, replace it immediately.

CAPACITY

For maximum capacity the hoist must be used with a double line. To achieve this the cable must be routed as follows: run the cable from the power unit to the pulley at the front of the trolley assembly then down through the tackle block and up again to the eye bolt at the front of the trolley assembly and secured.

Single line operation requires routing the cable through the pulley at the front of the trolley assembly and down to the load to be lifted.

WARNING: USING SINGLE LINE LOWERS THE CAPACITY TO NO MORE THEN 600LBS. NOT RESPECTING THIS WARNING MAY CAUSE DAMAGE, INJURY OR DEATH

IT IS RECOMMENDED TO USE 1500LBS OF COUNTERWEIGHTS REGARDLESS OF SINGLE OR DOUBLE LINE USE

PRE-START CHECKLIST

- Check engine and oil level. Follow engine manufacturers' recommendations as to type of oil to add if necessary (see engine manual).
- Check the engine air cleaner and air intake screen for dirt or obstruction. Clean as required.
- Fill the fuel tank with clean fuel. The requirements are listed in engine manufacturers' specifications.

WARNING; HANDLE FUEL WITH CARE. IT IS HIGHLY FLAMMABLE. USE APPROVED FUEL CONTAINER. NEVER REMOVE THE FUEL CAP OR ADD FUEL TO A RUNNING ENGINE. EXHAUST FUMES ARE DEADLY, DO NOT RUN ENGINE WITHOUT PROPER VENTILATION.

PRE-HOISTING CHECKLIST

1. Inspect all nuts/bolts and pins, tighten or replace as necessary.
2. Inspect all hooks, swivel latches and sheaves.
3. Inspect all hoisting accessories such as buckets, forks, etc.
4. Inspect cable, replace if damaged, worn or unravelled.
5. Be certain that the proper amount of counterweights is securely in place before hoisting operation begins.
6. Be certain that hoisting operation will clear all power lines and obstructions. Failure to do so may cause severe injury or electrocution.
7. Make sure all safety devices such as guards and operator fences are in place.
8. Oil and/or grease all necessary points.



9. Inspect and maintain unit as specified by manufacturer.
10. Make sure that hoisting area is clear of personnel at all times.
11. Make a few "dry runs" (no load) to test hoisting operation, controls, and power unit. It is best to keep 10-20 lbs. of tension on cable at all times to insure proper riding of cable on blocks and sheaves (Use cable weight).
12. Learn and use hoisting signals and discuss them prior to hoisting: an alternative means of communication is a hand-held walkie-talkie where working conditions warrant.

RULES FOR HOISTING


- Only trained personnel should operate hoist.
- Always follow pre-hoisting checklist before operating.
- Make sure the hoisting area is clear of power lines. Consult power company before you work near power lines. Take appropriate measures before you start. Insulating power lines for your protection from electrocution is a service that all utility companies offer their customers.
- Make sure hoisting area is clear of personnel at all times. Place barricades or markers if necessary.
- Do not exceed the rated capacity of any hoisting component.
- Check counterweight before hoisting, every time you use the hoist.
- Make sure load is secure before lifting.
- Do not normally hoist over open doorways. If you must, secure the area with barricades and markers.
- Use tag lines to control load.
- Check the hoist periodically during operation.
- Do not try to make adjustments while hoist is running.
- Keep fingers and clothes clear of machinery.
- When lowering, keep descent smooth and under control, avoiding sudden stops. Never let load "free-fall".
- At end of operation, all ropes and cables should be up and secured and trolley support should be retracted and secured to counterweight leg.
- Never assume you will find the hoist in the same condition that you left it. Take a few minutes to "look it over" before proceeding to hoist.
- Repairs should be made by authorized trained personnel.



RAISING TO ROOF

The Trolley Track hoists are shipped in sections for ease of transportation and assembly.

1. Position the sections at the base of the wall below the site of operation.
2. Use two or more men on the roof for lifting and one man on the ground with tag line to guide sections up, keeping them clear of the wall.
3. Raise the rear leg assembly to the roof and place it well back from the roof edge (approximately 25 feet)
4. Raise the front leg assembly and place it approximately 14 feet in front of the rear leg assembly, still keeping it at least 10 feet from the roof edge.
5. Raise the trolley rail and place it between the front and rear sections.




CAUTION; Insert handle pin (A) through the trolley rail at point (B) to prevent the trolley support (C) from rolling during transport and handling. This pin should remain in place until the power unit is raised and ready to be pulled onto the roof (as covered in the instructions for raising the power unit).

KEEP FINGERS AND HANDS FROM THE TROLLEY ASSEMBLY RUNNING AREA TO AVOID INJURY



ASSEMBLY

With the three sections in place and ready for assembly, well back from the roof edge, erection of the hoist can begin.




1. Remove spring lock pin (A) on the rear leg base (B) and raise the rear leg (C) to an upright position, reinstall pin (A)
2. Move the adjustment cylinder (D) on the rear leg to its lowest position by releasing the lock screw(s) (E) and re-tighten.
3. Slide the rear leg brace (F) into rail assembly (G) (rear).
4. Raise the rail assembly over the projection at the top of the adjustment cylinder (D) on the rear leg and secure with a handle pin (H) through the matching holes in the rail assembly and the adjustment cylinder projection.
5. Pin the rear leg brace (F) to the rail assembly with a handle pin (H) through the matching holes.
6. Raise the front frame brace (J) and tie temporarily to the top of the front frame assembly (K).
7. Release the spring lock pins (L) holding the operator fences (M) and swing fences 90 deg. to help support front frame during assembly.
8. Raise the trolley rail assembly and secure the front frame assembly with handle pin (N) through the matching holes in the front support of the rail assembly and the front frame pin tabs.
9. Untie the front frame brace (J) and secure to the rail assembly (G) with a handle pin (O) through the matching holes in the rail assembly rear support.
10. Swing the operator fence(s) outward to their protective wing positions on either side of the front frame.
11. To adjust the height of the rail assembly, raise it on both the front frame legs and the rear leg until it is in the desired position (generally at maximum height). Insert pins into each leg (front and rear), lower front frame and rear leg socket to rest pins and tighten lock screws (P and E).

NOTE; If not using track at maximum working height. Insert pin above adjustment cylinder on rear leg. The rail assembly should be slightly lower at the rear to facilitate pulling in loads.



12. Carefully move the entire unit to the edge of the roof carrying from the front frame and the rear leg assembly. The front frame assembly should be as level as possible, resting on a secure base several inches in from the roof edge. Holes are provided in the cross tie (Q) so it can be fastened to a 2 X 6 plank or plywood if desired.
13. Load counterweights on the rear leg base (B). Make certain they are properly nested. Tie the counterweights securely to the "D" rings (R) on the rear leg assembly to prevent accidental removal.
14. As an additional precaution, attach the stay wire (S) to a suitably fixed object on the roof.
15. Tighten all lock screws and be sure all lock pins are inserted.




WARNING; COUNTERWEIGHT MUST BE ONE AND ONE HALF TIMES THE MAXIMUM LOAD CAPACITY OF THE HOIST: 1500LBS



INSTALLING POWER UNIT

1. The trolley support assembly (A) should be rolled back past hole (B). Insert pin (C) into hole (B).
2. Lift the power unit and insert tube (D) on power unit over tube (E) on trolley support and insert spring lock pin (F) into respective holes.
3. Lift the power unit support arm (G) and line up its holes with trolley support bracket hole (H) and insert pin (J) which you will have removed from whole (B).



OPERATING THE MECHANICAL POWER UNIT (502500)

HOISTING THE LOAD

1. Start the engine and allow it to warm up.
2. Engage the safety pawl (D) onto the drum ratchet.
3. Move the power unit to the front of the front of the rail assembly, right up against the stopper.



MAKE SURE THE TROLLEY RAIL ASSEMBLY IS SEATED AGAINST THE STOPPER AT THE FRONT END OF THE RAIL, THIS WILL ENSURE THAT THE POWER UNIT IS IN ITS WORKING POSITION RIGHT UNDER THE POWER UNIT STOPPER ON THE RAIL ASSEMBLY. THIS STOPPER KEEPS THE POWER UNIT FROM PIVOTING WHEN FORCE IS APPLIED TO THE CLUTCH AND OR BRAKE LEVER.

NOT POSITIONING THE POWER UNIT CORRECTLY WILL RESULT IN OPERATOR FATIGUE AND DAMAGE TO CLUTCH AND BRAKE COMPONENTS

4. Increase the engine speed to desired level.
5. Raise the clutch handle (B) and brake handle (A) at the same time.
6. When the load is at the desired height, release the clutch handle and brake handle at the same time, this will stop and hold the load.
7. Pull the load onto the roof by using the stabilizer arm (C).
8. To lower the load onto the roof top, you must disengage the pawl (D).

LOWERING THE LOAD

1. Disengage the pawl. (D).

CAUTION: NEVER ENGAGE THE SAFETY LATCH WHILE LOWERING A LOAD

2. Move the power unit to the front of the rail assembly, right up against the stopper
3. Raise the brake handle (A) slowly until the load is lowering at the desired speed. Speed can be varied by raising or lowering the brake handle.

CAUTION: LOWER THE LOAD SLOWLY SO IT IS KEPT UNDER CONTROL AT ALL TIMES.

WARNING: AVOID SHOCK LOADS

Do not "jam" on the brake lever. This will cause a severe shock load which can result in equipment damage or personal injury.

CAUTION: RAISE AND LOWER LOADS SMOOTHLY, AVOIDING SUDDEN STARTS AND STOPS.



SAFETY HAZARDS

Safety hazards are not always obvious to workers. Unlike exposure to health hazards, where illness or injury develop slowly, safety hazards usually result in immediate injury or death.

Broken bones, cuts bruises, sprains, burns and loss of limbs, eyesight and hearing are the kinds of injuries caused by safety hazards.

The rate of occupational injuries in roofing, in fact, ranks in the top ten of all major occupational groups.

FALLS

Falls are the number one cause of serious injury and death to roofers. An estimated 10 percent of all roofing accidents result from falls off roof edges, through roofing openings or off ladders, more than half of the non-fatal accidents result in serious injury.

Unprotected and unguarded roof edges and roof openings create extremely hazardous conditions.

Ladders with cracked, loose or missing steps: with side rails broken or cracked and not attached firmly to the steps; with broken, loose or missing locks, or coated with grease, oils or hardened bitumen can lead to serious injury.

Ladders should always be inspected to make sure they're properly maintained and constructed and that they're long enough to extend three feet above the roof's surface.

Improperly balanced or unstable hoists overturn and will often carry the worker along. Rolls of roofing felt should never be used as counterweight. Workers should know the load capacity; it should be posted.

BURNS

Skin contact with hot asphalt and hot coal tar pitch usually results in second and third degree burns. They usually involve deeper portions of the skin and are easily infected.

An estimated 16 percent of all injuries are burns from hot stuff. The major causes of burns have been from:

Kettle flashes

- Kettle splashes from dropping pieces of coal pitch or asphalt into the kettle
- Slips and trips while carrying hot bitumen in open containers
- Splashes involving transfer operations like from the hot pipe outlet to a hot lugger, from a hot lugger to a mop cart or a pail, or from the kettle to a pail.

HEAVY LIFTING

Sprains and strains, a majority of which involve the back, are the most common roofing injury and one of the most severe. Almost 30 percent of these injuries result in 10 or more days away from work.



FIRE/EXPLOSION

Two conditions must be met in order for fires and explosions to occur. First, there must be an ignition source, a welding arc, spark, cigarette, flame or simply a hot spot as in a kettle or tanker. Secondly, there must be the right mixture of vapours (from asphalt, pitch, solvents) and oxygen.

For kettles and tankers, fire/explosion conditions arise when:

- oversized burners are used to fire the kettle, causing localized overheating of the heating tubes creating a hot spot
- the temperature of the bitumen is brought up to the desired operation temperature too quickly allowing the level of bitumen to drop to the level of the firing tubes, allowing excessively high surface temperatures
- heating the bitumen to its flash point (for asphalt, about 525°-540°; for pitch, about 450°-475°)
- the temperature of the bitumen is hot enough to reach the auto-ignition level
- in tankers, the vent pipe is clogged or plugged so that flammable vapours can build up to explosive levels

Many solvents evaporate quickly at roof temperatures. Explosive mixtures of vapours can be readily formed within confined spaces like high parapet walls, in atriums or in any space where little or no ventilation exists. And any kind of spark or flame can ignite the vapours.

ELECTROCUTION

Low voltage electricity can cause shock, muscle contractions, breathing difficulty, irregular heartbeat, severe burns and death. The route that the current takes through the body affects the degree of injury. Current flowing from one finger to another would not pass vital organ, while from one hand to another would pass through the heart and lungs.

Electrical tools should be properly grounded. The electrical cord should end in a three-prong grounding contact, or the wires should be enclosed in a metal case with a special grounding attachment.

Employers are required to provide ground fault circuit interrupters for all outlets on construction sites that are not part of the permanent wiring of the building. This is actually a fast-acting circuit breaker, which can shut off electricity in a fraction of a second.

Aluminum or other metal ladders pose a serious electrical hazard around electrical equipment and energized lines.

FALLING OBJECTS

Tools, bricks, materials, buckets, boxes, pallets or almost anything dropped from a sufficient height can cause severe damage. Head injuries, one of the highest compensated injuries to workers, often include brain damage. Workers need protective head gear when working beneath people, tools and equipment.

FLYING OBJECTS

Objects can be projected by machines, from welding or grinding operations and can be windblown. Tear-off operations, where power cutters, power brooms and power spudders are generally used, are the major source of flying substances. The part of the body most often injured is the eyes.

UNGUARDED MACHINERY

Exposed blades and chains on powered machinery like hoists and roof cutters can severely lacerate and crush parts of the body. Guards should always be fitted over moving parts to protect workers.

